



PARTS LIST

Item No.	Part No.	Qty.	Description
1	11475	1	Steel Case *
	09658	1	Aluminum ** *
2	09659	1	Impeller
3	11476	1	Motor
4	09661	1	Capscrew, Motor Shaft
5	1147	1	Flatwasher, Motor Shaft
6	09663	1	Lockwasher, Motor Shaft
7	11490	1	Plate, Motor Adapter
8	11478	1	Pump Support
9	11479	2	Screw, Flat Head
10	371500	2	Locknut, 1/2" NC
11	07209	6	Stud
12	07210	6	Wing Nut
13	07205	3	Leg Assembly
14	11480	1	Split Flange Kit 3/4"
15	11481	1	Split Flange Kit 1"
16	11482	1	Elbow, 1" x 3/4" JIC
17	11483	1	Elbow, 3/4" x 3/4" JIC
18	11484	2	Swivel, 3/4" JIC x 3/4 JIC
19	11486	1	Deflector Plate
20	07201	1	Gasket
21	11487	1	Connector, Aluminum
22	11485	1	Handle
23	07208	1	Eye Bolt, 3/8-16
24	00147	2	Hex Nut, 3/8-16
25	05152	1	Stanley Sticker
26	16602	1	GPM Sticker
	15875	1	Operating Warning Tag (Not Illustrated)

NOTE: Use Part Number and Part Name when Ordering.
 (1) is integral with aluminum casing on TP04014
 * Used on TP04013
 ** Used on TP04014

SEAL KIT DATA

Part No.	Qty.	Description
Seal Kit Part No. 04596		
07963*	1	Seal Kit
11507**	1	Seal Kit
07964	1	Seal
11046	1	Seal Washer
11047	1	Gland/Seal Carrier
11048	1	O-Ring
23568	1	Shaft Seal
21607	1	Installation Illustration

*Used for pumps with Hema motor
 **Used for pumps with Dowdy motor